



Revision
04/25/22

LC Holley Carb Adapter

Part # 1033005, 1033007, 1033009, 1033014, 1033016, 1033018

Thank you for purchasing our Holley300/500 Carburetor Adapter Kit. Please use the following guidelines for installation to achieve maximum performance and long service life from your adapter.

Since the Holley carburetor bores are so much larger than the stock manifold you will want to port match your mainifold to our adapter for optimal performance.

LC Engineering recommends pre installing the adapter up to your manifold to see where you will need to port match the manifold.

1. Pre install the adapter onto your manifold (no gaskets). Inspect the manifold opening and mark area to be port matched.
 - a. Any port work should be done with the manifold off the engine. Make sure to clean the manifold thoroughly after porting.
 - b. Install the four supplied studs into the top and bottom of your new adapter.
 - c. Use a small amount of threadlocker onto studs prior to installation into manifold.
2. Lightly coat lower gasket with white lithium grease on both sides (to help seal better) and install onto your manifold. Set your new adapter on top of the gasket.
3. Install adapter on intake manifold using the supplied allen bolts and wave washers to attach adapter to manifold.
 - a. Two bolts on top and two studs with washers and nuts on bottom.
 - b. Use a small amount of threadlocker onto hardware prior to installation.
4. Lightly coat carburetor gasket with white lithium grease on both sides (to help seal better). Install your carburetor onto the adapter and use washers and Nyloc nuts to tighten down. Do Not over tighten nuts or damage may accrue to the carb base.

Qty	Part
6	M8-1.25 x 45mm Full Thread Stud
6	M8-1.25 Nyloc Nuts
8	M8 Washer
2	M8-1.25 x 25mm Socket Head Cap Screw
1	Holley Base Gasket
1	Adapter to Stock 22R Manifold Gasket
1	Holley 350/500 Carb to 22R Manifold Adapter

